


6' DWARF Lean-To Assembly Instructions



NOMINAL SIZE	A (mm)	B (mm)
6ft x 6	1929	1990
6ft x 8		2610
6ft x 10		3230
6ft x 12		3850

NOMINAL SIZE	A (mm)	B (mm)
6ft extension	-	1860
8ft extension		2480
10ft extension		3100
12ft extension		3720



Thank you for purchasing your new Robinsons greenhouse. We recommend you familiarise yourself with the instructions and read all safety information before you commence assembly. This instruction manual is also available online at www.robinsonsgreenhouses.co.uk in our technical help section should you need to reprint it. Should you require any additional advice you can always call us on 01782 385409.

These instructions are divided into sections highlighted by a white number/letter on a black background at the bottom corner of most pages (see opposite page for details); **part lists**, **B**-base, **P**-preparation, **1**-side, **2**-front gable, **3**-rear, **4**-joining the three sides together, **5**-roof, **6**-wall attachment, **7**-vent, **8**-door, **9**-glazing, **10**-vent attachment, **11**-door attachment, **12**-anchoring down, **13**-optional louvre, **14**-optional shelf, **15**-optional staging, **16**-finishing touches, Door/s on side of structure rather than on or in addition to the gable/s. If you need to contact us for assistance please refer to the relevant section/s. If your building is longer than 12', i.e. has an extension then please also refer the separate extension manual.

Safety Warning

- Glass and aluminium can potentially cause injury. Please ensure you wear protective goggles, gloves, headgear and suitable footwear when assembling and glazing the building.
- Please remember that glass is fragile and should be handled with extreme care. Always clear up and dispose of any breakages immediately.
- Do not assemble the greenhouse in high winds.
- For safety reasons and ease of assembly, we recommend that this greenhouse is assembled by a minimum of two people.
- Please clear all lying snow from the greenhouse roof as it can cause the roof to buckle or collapse.

Site Preparation


- When selecting a site for your greenhouse, it is vital that you choose as flat and level an area as possible.
- A concrete or slabbed base will provide the most solid foundation for your greenhouse.
- IMPORTANT: Do **not** fix your building down until the building is fully assembled, including glazing.
- Avoid placing your greenhouse under trees or in other vulnerable locations.
- To minimise the risk of wind damage, try to select as sheltered a site as possible, e.g. beside a hedgerow or garden fence.

Additional Considerations

- Please bear in mind that assembling your greenhouse can be time consuming. You may need to spread the construction over two or more days. We recommend that you avoid leaving the building partially glazed. If you ever have to leave your greenhouse half assembled and not anchored down, weigh it down with slabs or bags of sand to stop the wind moving it.
- You will find it helpful to prepare a large, clean and clear area in which to work in. A garage floor or flat lawn area is ideal.
- If you have arranged for someone to install your greenhouse for you, please check that all components are included. Some parts are numbered and can be identified by a stamped or hand written number (without the 'D'). Alternatively, the components can be identified by their distinctive profiles, lengths and quantities detailed in the parts list (see next page).
- Anchoring down your greenhouse should be the final stage of construction (including glazing).
- Once installed your greenhouse requires little maintenance, but to maintain the smooth running of your door(s) WD40 or similar can be applied to the door wheels and lower door guides.

Guarantee

- Your new Robinsons greenhouse is guaranteed for 10 years against faulty manufacture of the frame-work. This does not include glazing, moving parts, accidental damage or wind damage.



KEY SYMBOL	KEY DESCRIPTION
	EXTERNAL VIEW
	INTERNAL VIEW
	THINK
	THIS SECTION RELATES TO ANOTHER (e.g. 1 to 5)
	CORRECT
	DO NOT FIX DOWN!
	TWIST TO LOCK
	TIGHTEN
	PUSH AND HOLD
	CUT TO LENGTH

SECTION No	TITLE	ASSEMBLY SYNOPSIS: IMPORTANT INFORMATION / CONSIDERATIONS
B P 1 2 3 4 5 6 7a 7b 8 9 10 11 12 13 14 15 16	PARTS LIST	Most components should have a 'D' code punched into their metal surface. Identify and separate all like for like components prior to assembly. The 'parts list' also separates parts into the various sections 1 - 12 shown below. Parts can also be identified by their profile pictures and stated lengths etc..
	BASE	Base dimensions and recommendations. Ensure that your base is level as this will make assembly of the building, especially the glazing of the roof much more straight forward.
	PREPARATION	Tools required. IMPORTANT: Use WD40 or similar in the glazing bar channels and insert the black glazing rubber prior to frame assembly.
	SIDE	Take the side glazing bars 'D609' with the rubber inserted and the diagonal braces 'D604', use 10mm bolts to join them to the gutter and 15mm bolts to the cills (note how the head of the bolt slides into each glazing bar during construction).
	FRONT	Again ensuring that the gable framework is rubbered-up follow the diagrams to assemble each end of the building. Make sure that you have inserted the extra bolts utilised in sections 4, 5 and 11. On the roof and side corner bars not every rubber channel will require rubber unless it is to be utilised in a partition (see separate manual and section P).
	REAR	
	JOINING THE THREE SIDES	Take the side (1) and both gables (2 & 3) and join them together on your base. It is a good idea to tie some ladders to the side to support them if you do not have anyone to hold them for you.
	ROOF	Attach the ridge and then the rubbered-up roof bars ensuring that they are fully butted up to the ridge and down onto the gutter. Some tubular braces are supplied to add extra strength, they can be fitted now or later with crop head bolts.
	REAR WALL ATTACHMENT	The main body of the frame is complete it can be attached to the wall. Make sure that the wall bars are vertical and the ridge is horizontal then drill and screw the building to the wall. Do not attach the base to the ground until section (12) as your building may not be square.
	VENT	Once the vent is glazed add silicone to the vent sides and top. Stand the vent/s on their hinge (vent top) and then leave the silicone to set.
	VENT SLAM	The slam bar 'D079' can be moved up and down between the roof glazing bars so that it can be butted down onto the pane of glass beneath, the autovent will be attached to it later on (10).
	DOOR/S	Construct the door using the diagrams and then leave to one side ready for attachment in section (11).
	GLAZING	Layout the bar cappings and covers around the building like a sundial checking that all is present and correct. You can also place the roof cappings in the gutters so they are closer to hand. You will notice that your roof cappings (D541 / D547) are in one long section however you can cut this into two sections if you wish due to the glass overlap in the roof. This will remove the bulge in the roof capping, however keep the roof cover strips (D544) full lengths for the neatest finish. The glass in the ends has to bevel on the black separator strip, this bevelling action allows the glass to tuck underneath the roof corner canopy. Use the capping and the self tapping screws to then hold the glass in place. The covers then enclose the screw heads giving a neat finish. A top tip is to not attach the door post capping (D814/D836) until you have fitted the door runner and threshold (11) to give you more room to manoeuvre.
	VENT ATTACHMENT	Take the assembled vent and slide the vent hinge 'D866' into the end of the ridge allowing the vent the pivot open and closed. Vent stops go either side of the vent to stop any lateral movement (so insert stop / vent / stop). Attachment of the Bayliss XL autovents.
	DOOR ATTACHMENT	Use the bolts inserted in section (2) to attach the upper door track. The lower door runner 'D860' and ramp threshold 'D087' push down and lock together. Please note that if you are putting the door on the left hand gable (as you look at wall) the door track and runner will go from the doorway towards the gutter and if you are putting the door on the right hand end the track and runner will open towards the wall.
	ANCHORING DOWN	Now that the greenhouse is finished and the door and vent/s are operating without interference then you need to anchor the building down using 2" rawl plugs and screws. Use a 7mm masonry bit in a hammer drill to create the holes.
	OPTIONAL LOUVRE	They attach to the building during the glazing process (9) like a piece of glass with a black separator above and below them.
	OPTIONAL SHELIVING	Robinsons integral cantilever staging and shelving attaches to the inside of the greenhouse frame using either square head bolts (insert four into each side glazing bar 'D609' during construction of the sides (1)) or rectangular 'crop head' bolts which can be fitted retrospectively (both sets of bolts accompany the shelving/staging). This system allows the height of either the staging or the shelf to be set at an operator specific height. Commonly the staging brackets are set 900mm from the cills though you can alter this to suit the end user/s. The aluminium shelf / staging slats come in two lengths; (4'):1240mm 'D2002' and (6'):1860mm 'D2003'. These slats can combine to create any length of staging required, i.e. 4'+6' = 10' etc...
	OPTIONAL STAGING	
	FINISHING TOUCHES	Now that the main body of the structure is complete you can add; downpipe fittings, eave bungs.

Section Ref	Part No.	Section	Size (mm)	6lt 6	6lt 8	6lt 10	6lt 12
-------------	----------	---------	-----------	-------	-------	--------	--------

1	D043		1894	1			
	D021		2514		1		
	D022		3134			1	
	D023		3754				1
	D975		1897	1			
	D974		2517		1		
	D979		3137			1	
	D978		3757				1
	D604		1316	2			
	D609		1160	2	3	4	5
	RUBBER		1000 (1m)	5	7	10	12
	D174		N/A	2	2	4	4

2 +	D961		1894	1			
	D628		650	1			
	D605(R)		690	1			
	D606(L)		690				
	D632L		650	1			
	D632R		650				
	D608		1160	2			
	D955		2037	1			
	D956		2147	1			
	D985		1480	2			
	D992		1267	1			
	D993		1377	1			
	D962		1890	1			
	D950L		1915	1			
	D950R			1			

6' DWARF lean to











Section Ref	Part No.	Section	Size (mm)	6lt 6	6lt 8	6lt 10	6lt 12
-------------	----------	---------	-----------	-------	-------	--------	--------


2 +	RUBBER		1000 (1m)	29			
3	D174		N/A	8			

5	D976		1897	1			
	D973		2517		1		
	D981		3137			1	
	D977		3757				1
	D962		1890	1			
	D113		2510		1		
	D918		3130			1	
	D034		3750				1
	D951		1915	2	3	4	5
	RUBBER		1000 (1m)	8	12	16	20

7	D866		639	1	1	2	2
	D863L		613	1	1	2	2
	D863R		613	1	1	2	2
	D862		593	1	1	2	2
	D079 PLUS FLUFF		590	1	1	2	2
	D114		N/A	2	2	4	4
	D220 PLUS FS6060 SCREW		N/A	2	2	4	4
	D205		N/A	2	2	4	4

Section Ref	Part No.	Section	Size (mm)	6lt 6	6lt 8	6lt 10	6lt 12
-------------	----------	---------	-----------	-------	-------	--------	--------




8	D090 + D347 lock = D301		1824	1			
	D094		1824	1			
	D096 + D217 wheel = D307		611	1			
	D095		611	1			
	D097		611	1			
	D232		905	2			
	D233		797	2			
	P053		N/A	1			
	D225		610	1			
	D840B		4000	1			













MAIN FRAME QUANTITIES VENTS / DOORS etc SEPERATE		10mm	16	19	22	25
		15mm	31	32	33	34
		m6	47	51	55	59







6' DWARF lean to

Section Ref	Part No.	Section	Size (mm)	6lt 6	6lt 8	6lt 10	6lt 12
-------------	----------	---------	-----------	-------	-------	--------	--------


9	5	D541		1915	2	3	4	5
	1	D618		1144	2	3	4	5
	2	D969		140	1			
	2	D971		250	1			
	3	D987		1370	1			
	3	D991		1260	1			
	5	D547		1915	2			
	1/2/3	D620		1144	4			
	2	D814		1883	2			
	2/3	D986		1480	2			
	5	D544		1915	4	5	6	7
	1/2/3	D619		1144	6	7	8	9
	2	D836		1883	2			
	2	D970		140	1			
	2	D972		250	1			
	3	D988		1370	1			
	2/3	D989		1480	2			
	3	D990		1260	1			

11	D864		590	1			
	D860		1240	1			
	D087		587	1			
	D084		1270	1			
	D083		1270	1			
	D153		198	1			
	D163		90	2			
	D154		N/A	1			
	D222/B		590	1			
	D112		650	1			
	D845		N/A	2			
	D842		N/A	1			






6
X 1




D975




D043

6 X 1 DWARF		
Part No	mm	Quantity
D975	1897	1
D043	1894	1
D609	1160	2
D604	1316	2
D174		2
M6-10mm		2
M6-15mm		4
M6-NUT		6
Rubber	1000	5

e.g. ①



8
X 1




D974




D021

8 X 1 DWARF		
Part No	mm	Quantity
D974	2517	1
D021	2514	1
D609	1160	3
D604	1316	2
D174		2
M6-10mm		3
M6-15mm		5
M6-NUT		8
Rubber	1000	7


e.g. ②



10
X 1



D979




D022


10 X 1 DWARF		
Part No	mm	Quantity
D979	3137	1
D022	3134	1
D609	1160	4
D604	1316	2
D174		4
M6-10mm		4
M6-15mm		6
M6-NUT		10
Rubber	1000	10




SPECIALLY ORDERED
OPTIONAL SINGLE / DOUBLE
DOOR ON SIDE?




e.g.



12
X 1







D978



D023


12 X 1 DWARF		
Part No	mm	Quantity
D978	3757	1
D023	3754	1
D609	1160	5
D604	1316	2
D174		4
M6-10mm		5
M6-15mm		7
M6-NUT		12
Rubber	1000	12






Part No	mm	Quantity
D605(R)	690	1
D608	1160	1
D628	650	1
D632L	650	1
D950R	1915	1
D955	2037	1
D956	2147	1
D985	1480	1

DOOR ON LEFT
EXTERNAL
VIEW




Part No	mm	Quantity
D174		4
D227		16
M6X10		8
M6X15		10
M6NUT		18








DOOR ON RIGHT
EXTERNAL
VIEW



Part No	mm	Quantity
D606(L)	690	1
D608	1160	1
D628	650	1
D632R	650	1
D950L	1915	1
D955	2037	1
D956	2147	1
D985	1480	1




2




Part No	mm	Quantity
D608	1160	1
D950L	1915	1
D961	1894	1
D962	1890	1
D985	1480	1
D992	1267	1
D993	1377	1

DOOR ON
LEFT
EXTERNAL
VIEW












Part No	mm	Quantity
D174		4
D227		11
M6X10		5
M6X15		10
M6NUT		15







DOOR ON
RIGHT
EXTERNAL
VIEW




Part No	mm	Quantity
D608	1160	1
D950R	1915	1
D961	1894	1
D962	1890	1
D985	1480	1
D992	1267	1
D993	1377	1














6'		
		4
Part No	mm	Quantity
D976	1897	1
D951	1915	2
D962	1890	1
RUBBER	1000	8


8'		
		6
Part No	mm	Quantity
D973	2517	1
D951	1915	3
D113	2510	1
RUBBER	1000	12

10'		
		8
Part No	mm	Quantity
D981	3137	1
D951	1915	4
D918	3130	1
RUBBER	1000	16


12'		
		10
Part No	mm	Quantity
D977	3757	1
D951	1915	5
D034	3750	1
RUBBER	1000	20





1



2





6

6x6 6x8 6x10 6x12						
Part No		mm	Quantity			
SYSCR3		75	9	10	11	12
SYRAWL		50	9	10	11	12




3



There are various methods for attaching your greenhouse frame to its wall.





- 1) Drill through the vertical wall bars with a 7mm drill/hammer drill using a 7mm masonry bit, Use 3" screws to secure the wall bars.
- 2) Drill through the vertical wall bars with a 7mm drill bit and enlarge the inner hole to 10mm. Use 2" screws to secure the wall bars hiding the screw heads inside the bars to give a neat finish.
- 3) Use L-shaped brackets and 2" screws to secure the frame to the wall similar to anchoring the greenhouse down (e.g. section 12).

6





Part No		mm	Quantity
D866		639	1
D863L		613	1
D863R		613	1
D862		593	1

Part No		mm	Quantity
D220 PLUS FS6060 SCREW		N/A	2
D205		N/A	2
SY-BOLM6X11		10	4
SYNUTM6		M6	4
8 X 12 S/T FS6017		10	2
8 x 19 S/T FS6018		19	2




7a




3 






D862



4 









5 




7a

1 vent
slam bar = {





Part No		mm	Quantity
SY-BOLM6X11		10	2
SY-BOLM6X15		15	2
SYBOLM6 X11CROP		10	2
SYNUTM6		N/A	4


Part No		mm	Quantity
D079 PLUS FLUFF		590	1
D114		N/A	2

6





7b
















Part No		mm	Q
D090 + D347 lock = D301		1824	1
D094		1824	1
D096 + D217 wheel = D307		611	1
D095		611	1
D097		611	1

Part No		mm	Q
D232		905	2
D233		797	2
P053		N/A	1
D225		610	1
D840B		4000	1
D263 PACK		N/A	7
		N/A	7
D260 PACK		N/A	12






PART No	Section	Size (mm)	e.g.
D541		1915	
D618		1144	
D969		140	
D971		250	
D987		1370	
D991		1260	
D547		1915	
D620		1144	
D814		1883	
D986		1480	
D544		1915	
D619		1144	
D836		1883	
D970		140	
D972		250	
D988		1370	
D989		1480	
D990		1260	




e.g.



e.g.



e.g.









e.g.








6' DWARF LEAN-TO TOUGHENED GLASS









PART No		Size (mm)	6'	8'	10'	12'
D1216	S	610 X 1162	7	8	9	9
D964	R	610 X 1312	3	4	5	6
D963	W	610 X 630	2	3	3	4
D1208	A	610 X 610	1	1	2	2
D911	C	555 X 812	1			
D912	D	555 X 922	1			
D965	F	ANGLE	2			
D966	E	ANGLE	2			
D967	G	ANGLE	1			
D968	H	ANGLE	1			
D222/B		590 long	1			
D101 / ROSEPS	H	610 long	5			










D624	M	610 X 550	1
D729	L	525X 100	6
D101 / ROSEPS	H	610 long	1
















Part No		mm	Q
D864		590	1
D084		1270	1
D083		1270	1



Part No		mm	Q
D163		90	2
D845			2
SY-BOLM6X15			8
SYNUTM6			8






11




Part No		Q
D860		1
D087		1






5







11





Part No		Q
D842		1
D112		1
SYBOLM6 X11CROP		3

7







Part No		Quantity
FS6018		1
D312		2
D204L /B		1
D204R /B		1


8






11










12




Part No		mm	Quantity
D168L		552	1
D168R (handle)		552	1
D165		612	2
D166		552	2
FS6013		12	4










Example: 2x 4' **3** slat shelves 'ST0304' = 8' run













Example: 2x 4' 7 slat staging 'ST0704' = 8' run













Part No		mm	Q
D512		1210	1
D086		2510	1
D085		2510	1

Part No		mm	Q
D522		50	1
D163		90	2
D150			1
D845			2
SY-BOLM6X15			13
SYNUTM6			13





Please be aware that this is a multi-national manual, if you spot any errors or have any constructive comments regarding the manual please email james.spooner@greenhousepeople.co.uk and I will make the necessary amendments. Whilst the information contained in this booklet is accurate at the time of publication, changes in the course of Robinsons policy of improvement through development and design might not be indicated. We point out this fact to avoid any infringements of the Trade Descriptions Act and also to advise that Robinsons Greenhouses reserve the right to change specifications and materials without prior notice.

In addition any photographs of completed buildings would be most appreciated to add to our portfolio.

THIS GREENHOUSE BOX WAS PACKED BY:

DATE: _____



www.robinsonsgreenhouses.co.uk

To contact Robinsons Customer Services email us at sales@robinsonsgreenhouses.co.uk or call us on 01782 385 409.

Our address is Robinsons Greenhouses, Unit 19 Blythe Park, Cresswell, Stoke-on-Trent, Staffordshire, ST11 9RD